







WARNING  
DO NOT TOUCH  
INTERNAL PARTS

DO NOT  
EXPOSE  
TO  
WATER

DO NOT  
REMOVE  
THIS  
LABEL

INSTALLATION INSTRUCTIONS

3" HOOKS

CONSTRUCTION CABINET

INSTALLATION INSTRUCTIONS

1. REMOVE THE TOP PANEL FROM THE CABINET.

2. ATTACH THE 3" HOOKS TO THE TOP PANEL.

3. ATTACH THE TOP PANEL TO THE CABINET.

4. ATTACH THE DOOR TO THE CABINET.

5. ATTACH THE HANDLE TO THE DOOR.

SUN WEST ENGINEERING, INC.  
201 - 2000 - 10000 - 10000 - 10000 - 10000

INSTALLATION INSTRUCTIONS