







LEFT-HAND MOUNTED INSTALLATION INSTRUCTIONS

1. REMOVE THE DOOR AND HINGES FROM THE UNIT. (SEE PARTS LIST FOR PARTS TO BE REMOVED.)
2. REMOVE THE FRONT PANEL FROM THE UNIT.
3. REMOVE THE PANEL FROM THE UNIT.
4. REMOVE THE DOOR AND HINGES FROM THE UNIT. (SEE PARTS LIST FOR PARTS TO BE REMOVED.)

LEFT-HAND MOUNTED

FRONT PANEL

DOOR

SLAY WEST ENGINEERING, INC.
 1000 S. 10th St., Suite 100, San Jose, CA 95128
INSTALLATION INSTRUCTIONS

INSTALLATION INSTRUCTIONS

1. REMOVE THE UNIT FROM THE CABINET.
2. REMOVE THE BELTS FROM THE UNIT.
3. REMOVE THE CABINET FROM THE UNIT.
4. REMOVE THE PLYWOOD BACKSHEETS FROM THE UNIT.

BELTS

CABINET

PLYWOOD BACKSHEETS

SLAY WEST ENGINEERING, INC.
 1000 S. 10th St., Suite 100, San Jose, CA 95128
INSTALLATION INSTRUCTIONS



LETTER OF TRANSMITTAL
INSTALLATION INSTRUCTIONS

NOTICE TO THE USER

- READ ALL INSTRUCTIONS CAREFULLY BEFORE USING THIS PRODUCT.
- THIS PRODUCT IS FOR USE ONLY AS DESCRIBED IN THESE INSTRUCTIONS.
- THIS PRODUCT IS NOT TO BE USED FOR ANY OTHER PURPOSE.

SUN WEST ENGINEERING, INC.
1001 S. 1000 E., P.O. BOX 4, BENTON, AR 72015-0004

INSTALLATION INSTRUCTIONS



